



All Elbows to be Schedule 80 Long Sweep (36")
 Unless Noted Otherwise

NOTES:

1. Customer responsibilities:

- ◆ Digging all trenches
 - ◆ Installing conduit
 - ◆ Installing necessary concrete pad per VEC specs
1. Top of concrete pad should extend above the finished grade 2" to 3".
 2. Top of concrete pad must be level.
 3. Back fill under concrete pad must be thoroughly compacted.
 4. Do not back fill with rocks or debris.
 5. VEC representative must inspect work before back filling can begin.
 6. Marking tape (furnished by VEC) should be placed 12" above top of conduit.



Installation Guidelines Underground Service with Underground Transformer - Concrete Pad	
Revised 01/07/04	Drawn By CKD